

# Pressure sensors SPAW with display

Type codes

SPAW - B2 R - G12 M - 2P - M12

**Type**

SPAW	Pressure sensor
------	-----------------

**Pressure measuring range [bar]**

B2	-1 ... +1
B11	-1 ... +10
P2	0 ... 2
P6	0 ... 6
P10	0 ... 10
P16	0 ... 16
P25	0 ... 25
P50	0 ... 50
P100	0 ... 100

**Supply port**

R	Relative pressure
---	-------------------

**Pneumatic connection**

G12	G 1/2
G14	G 1/4

**Thread type**

F	Internal thread
M	External thread

**Electrical output**

2P	2xPNP
2 N	2xNPN
2PA	2xPNP, 1 analogue output 4 ... 20 mA
2PV	2xPNP, 1 analogue output 0 ... 10 V
2NA	2xNPN, analogue output 4 ... 20 mA
2NV	2xNPN, analogue output 0 ... 10 V

**Electrical connection**

M12	Plug M12, A-coded
-----	-------------------